Knight®
by Midmark

Dental Chair Armrest Installation Instructions

Insert ARMREST ASSEMBLY into proper PIVOT POST. NOTE: There is a left and right hand ARMREST. The ARMREST is in the proper position when the notch located above the slot is orientated to the outside of the chair. When the ARMREST is parallel to the side of the CHAIR the slot at the bottom of the PIVOT POST will engage the LOCATING PIN inside the PIVOT POST and hold the ARMREST in position.

Turn the SET SCREW in the PIVOT POST untill it is tight. Back the SET SCREW out approximately 1/4 turn. This will allow the ARMREST to be lifted out slightly at its pivot point and rotated, but will prevent complete removal of the ARMREST. NOTE: SET SCREW IS DESIGNED TO TURN HARD.